

Installation of a knockdown frame:

Simple knockdown frame: follow steps 1, 2 and 3

Knockdown frame with lateral window: follow steps 1 trough 6

1. Firmly press to place the header; determine the opening side of door.
2. Place the top of jamb in header to box around wall, until you've reached a vertical straight making sure the jamb is well pressed to floor. Follow these steps for the other jamb as well.
3. Solidly affix both jambs to the floor with the provided brackets.
4. Insert the floor base in its place, then, insert the top center mullion (vertical) in the appropriate fitting on the header, leaving from the mullion base to the floor approximately 8 inches. This allows the installation of the center rail (horizontal) to the appropriate fitting on the jamb. Then, box in the center rail with the mullion; setting in its definitive place.
5. Once the center rail and the bottom of the glass section are adjusted, as well as the center mullion, solidly affix the frame to the floor with the provided brackets.
6. Put the door in place and finish adjustments with pressure screws.

** Please note: in the case of door frames equipped with sills, they are to be installed before final adjustments are made.

